




You don't have to switch both Load & Neutral
 We switch the neutral and fuse the load



01 SILK SCREEN COMPONENT SIDE

02 COMMON PADS

06 BOTTOM TRACES (FOIL SIDE)

30 BOARD OUTLINE